

Cut pieces of paper as shown - make sure the width of each piece is the same. Tape them together in the bays against the outside walls. A line drawn from the outside corner to the inside corner is the miter angle for the Baseboard or Crown.

"Find Miter" slideshow

