## #3 Base Loops

Install the Dividers and Attic Partition, but not the Blind Dividers or Bathroom Dividers (if customizing).

Mark the Base Loops 3/4" above the floors with the Layout Stick.



O"Folded Corners" are pleated re-directs that go around doors or windows.



The first fold is away from the new direction.



The second fold is toward the new direction.



Do Not eyelet a folded corner

