

Using the Stair hole:

This alternative to the Main Loop is an acceptable way to wire into the attic because of all the redundant connections to the house wiring (circles). Each parallel connection decreases load and increases reliability.



... but, wiring with parallel connections *requires* copper-to-copper and blue-to-blue at *every* connection.